



20976 INSTALL INSTRUCTIONS

Part #	Description	QTY
20976A	Billet Adapter	1
P712	Rubber Sleeve w/ Clamps	1
P9861	LT1 KN Air Filter	Sold Separately

**P712 includes 2 clamps. P9861 includes one additional clamp



1. 20976A can be installed up or down to raise or lower the air filter as desired.
2. Install air filter on either end of the adapter. This is easiest done on a workbench as the filter opening lips need to go around the end of the adapter as seen to the right. Secure with a clamp. Some oil may have to be wiped off of the filter initially.
3. Attach the rubber sleeve to one end of the filter. Secure with a clamp.
4. Attach the assembly to the intake on your engine using the final clamp.